



FLAT BOX BEAD GUIDES - FBBG

Tapepro Flat Box Bead Guides are designed to be fitted to Tapepro, Blueline, or Premier boxes and provide a spring loaded guide for use on external corners or shadow bead.

To fit the Bead Guides:

1. If your box does not have a hole in the side plate adjacent to the skids, drill a 2mm (5/64") hole in each side plate.
2. Remove the F007 screws retaining the skid, then fit the Bead Guide, feeding the spring in as shown:
3. Secure with supplied screws (AT234) and bushes (F056).
4. Test operation.

